

AD-A052 678

B-K DYNAMICS INC ROCKVILLE MD

F/G 9/2

QUARTERLY INTERIM TECHNICAL REPORT (2ND), CONTRACT DAAH01-75-C---ETC(U)

APR 75

DAAH01-75-C-0194

UNCLASSIFIED

BKD-TR-3-192

NL

1 OF 1  
AD  
A052678



END  
DATE  
FILMED  
5 -78  
DDC

AD A 052678

UDC FILE COPY

0

DDC  
APR 14 1978  
A

DISTRIBUTION STATEMENT A

Approved for public release;  
Distribution Unlimited

AD A 052678

①

⑭

BKD - TR-3-192

⑥

~~2nd~~ Quarterly Interim Technical  
Report (2nd),  
Contract DAAH01-75-C-0194

⑪

15 Apr 1975

⑫

88 p.

⑮

DAAH01-75-C-0194

⑨

Rept. for 15 Jan - 15 Apr 75.

AD NO.

DDC FILE COPY

DDC  
RECEIVED  
APR 14 1978  
REGULATORY  
Q & A

DISTRIBUTION STATEMENT A

Approved for public release  
Distribution Unlimited

B&K

DYNAMICS, INC.

387 575

TABLE OF CONTENTS

**BOK**  
DYNAMICS, INC.



## TABLE OF CONTENTS

	PAGE
1.0 INTRODUCTION	1
2.0 INTERIM STINGER SIMULATION ACTIVITIES	1
3.0 STINGER CONVERSION TO ASC EQUIPMENT	2
3.1 SOFTWARE CONVERSION	4
3.2 SOFTWARE TEST	6
3.3 SYSTEM SOFTWARE AND INTERFACE CHECKOUT	6
3.4 REAL-TIME I/O	7
APPENDIX A GENERAL PURPOSE AD/4 TEST PROGRAM	A-1
APPENDIX B AD/4 - SDS/9300 DISCRETES CHECKOUT PROGRAM	B-1
APPENDIX C 3010 DIAGNOSTIC PROGRAM	C-1
APPENDIX D FORTRAN HYBRID SOFTWARE	D-1
APPENDIX E DADIOS CHECKOUT PROGRAMS	E-1

## LIST OF FIGURES

FIGURE 1. THE INTERIM STINGER REAL-TIME SIMULATION	3
FIGURE 2. PHASE 1 STINGER CONVERSION TASK	5
FIGURE 3. DADIOS PATCHING REQUIREMENTS	8

ACCESSION NO.	
RTM	White Section <input checked="" type="checkbox"/>
DDC	Buff Section <input type="checkbox"/>
UNANNOUNCED	<input type="checkbox"/>
JUSTIFICATION	
BY <i>Mr. Lamm 50</i>	
BY <i>on file</i>	
DISTRIBUTION/AVAILABILITY CODES	
Dist.	Avail. sec. or special
A	23


## 1.0 INTRODUCTION

B-K Dynamics' activities during the second quarter (15 January 1975 to 15 April 1975) have been focused on two areas: preparation of hardware for the interim STINGER simulation and conversion of the STINGER simulation to the ASC's hybrid computer system. This report summarizes the work performed during the above period.

## 2.0 INTERIM STINGER SIMULATION ACTIVITIES

BKD's interim STINGER simulation activities have been associated with readying the hardware for data transmission between the major system components (i. e. SDS/9300 to AD-4 and SDS/9300 to GE/3010). AD-4 linkage hardware, including the AD-4 converter and hybrid interface unit, was exercised and evaluated for performance. Sample/hold amplifiers were calibrated and data transmitted from the AD-4 to the IRSS using the SDS/9300. These tests were successful.

During the quarter, IRSS interface operation was intermittent. Extensive testing was done to discover the source of errors generated in data exchanges. Grounds, power supplies and other potential sources of noise were investigated. The problem was finally resolved by the replacement of several marginal gates, relocation of driver/receiver cards to the GE/3010's CPU chassis, and modification of the ground system. In the course of the above activities, software was generated for use in checking the SDS/9300 to GE/3010 link and the SDS/9300 to AD-4 link. Specifically, three programs were developed;

- 
- A general purpose AD-4 test routine,
  - An AD-4 discrete test routine, *and*
  - A GE/3010 interface test routine.

The general purpose AD-4 test routine contains an ADC read loop and a register read/write loop along with three additional buffer areas for storing programs for the AD-4. Code for the AD-4 is entered in the buffers and executed from the SDS/9300 under sense switch control. The program is documented in Appendix A.

The AD-4 discrete test routine provides a convenient method for verifying that the 16 input and 16 output lines between the SDS/9300 and the AD-4 are operating. In addition it verifies the operation of DGS's and DGC's on the AD-4. The program is described in Appendix B.

The SDS/9300 to GE/3010 interface test program verifies the operation of that link. The program has two options for data transmitted. A count from 000000<sub>8</sub> to 177777<sub>8</sub> in increments of 1 bit is normally transmitted and optionally a pattern of all ones alternating with all zeroes may be sent. The data is transmitted from the SDS/9300 to the GE/3010 and then read back and compared. The program is described in Appendix C.

### 3.0 STINGER CONVERSION TO ASC EQUIPMENT

Converting the STINGER real-time simulation from the interim system to the ASC equipment has required replacing IBM-7094 software functions with equivalent CDC-6600 functions, and IBM-DOS interface operations with equivalent DADIOS ADC, DAC and discrete word handling capabilities. In Figure 1 the relationship of hardware




FIGURE 1  
THE INTERIM STINGER REAL TIME SIMULATION



elements in the interim simulation are shown. The elements which are affected in this phase of the conversion are outlined in heavy borders.

To date STINGER software conversion and DADIOS checkout routines have both been completed. In addition a preliminary real-time I/O design has been developed based on results obtained from DADIOS checkout studies. The final real-time checkout will require extensive hardware/software test and the successful integration of the new software with the existing STINGER simulation. The flow chart in Figure 2 shows the interrelationship between these tasks. The tasks outlined in solid lines represent those completed.

### 3.1 SOFTWARE CONVERSION

The interim STINGER simulation has approximately 2500 lines of code written for the IBM/7094. Of this code approximately 2000 lines of code are in FORTRAN and 500 lines are in MAP (7094 assembly language). Converting this software to the CDC-6600 required minor changes to the FORTRAN code and a completely new code written in FORTRAN hybrid to replace the IBM-7094 assembly code. Conversion of the assembly language portion of the code has been accomplished by 1) generating a flow chart from the MAP code, 2) rewriting in FORTRAN hybrid the equivalent functions and 3) incorporating the appropriate real-time input/output. In Appendix D the equivalent FORTRAN hybrid code is given. The statements labeled SOFT-T are modifications pertaining to the software testing.




FIGURE 2  
PHASE 1 STINGER CONVERSION TASK



### 3.2 SOFTWARE TEST

In order to reduce real-time software testing all new software will be tested in three steps: First, the new software will be simulated in non-real-time using special software to simulate real-time functions. Secondly, the software will be tested in pseudo real-time, a real-time test which uses only the most critical real-time loop. Then, if the previous tests are successful, the software will be tested in real-time. Evaluation of software test results will consist primarily of comparing interim STINGER data acquired from current simulation runs with results obtained from the new software.

In Appendix D the software necessary for simulating real-time events is presented. The special tasks which simulate hardware I/O are identified in card columns 73 through 80 by the designator SOFT-T. Other tasks which correct inconsistencies between the FTH. compiler and FTHH. are denoted by the designator SOFT-MOD.

### 3.3 SYSTEM SOFTWARE AND INTERFACE CHECKOUT

Prior to real-time simulation the system software and interface must be verified. This type of testing is important for 1) verifying status of the real-time system software and 2) checking the accuracy of ADCs, DACs and discrete communication. The test routines completed thus far include the following:

- Verification of discretes from AD-4 to CDC-6600.
- Verification of discretes from CDC-6600 to AD-4.
- Verification of ADCs from AD-4 to CDC-6600.
- Verification of DACs from CDC-6600 to AD-4.

In addition to establishing equipment status prior to real-time simulation, these test procedures are also used for isolating hardware or software failures in the interface system. In Appendix E the checkout programs are presented with an explanation of usage given in the code.

### 3.4 REAL-TIME I/O

The real-time I/O operations previously handled by the IBM-DOS are now implemented on the CDC-6600/DADIOS system. These new I/O task have been implemented in the FORTRAN hybrid code (Appendix D). These modifications will provide the STINGER simulation with the following hybrid linkage hardware:

- 16 Logic trunks from AD-4 to CDC-6600.
- 16 Logic trunks from CDC-6600 to AD-4.
- 16 DACs from CDC-6600 to AD-4.
- 16 ADCs from AD-4 to CDC-6600.
- 3 Interrupt lines from AD-4 to CDC-6600.

The AD-4 trunkline and ASFISS trunking station assignments are shown in Figure 3.




FIGURE 3  
DADIOS PATCHING REQUIREMENTS

APPENDIX A

GENERAL PURPOSE  
AD/4 TEST PROGRAM



## GENERAL PURPOSE AD-4 TEST PROGRAM

### PURPOSE

The General Purpose AD-4 Test Program permits the user to execute up to five separate AD-4 routines (e. g. ADC read, register read/write etc.) under sense switch control. The program contains a register read/write routine and an ADC read routine. Three other program areas are available for the user to enter his own code.


### USAGE

- Five AD-4 command lists are defined at locations 02100, 02200, 02400 and 02500. The first word of each list consists of the word count of that list. Subsequent words are the actual AD-4 command list words.
- If switch n is on, then list n will be sent. However, if the word count is LE 0 for a given list, that list is not sent even if the corresponding switch is on.
- New command lists may be added to the deck or loaded separately.
- OPERATION. Load the program. To run it perform the following sequence:

IDLE, RESET, RUN, INT33


If one pass is desired set SS6 then set SSn for execution of the AD-4 program. The program will loop at location 01127 when complete. Results will be stored at locations 60000<sub>8</sub> to 60100<sub>8</sub>.

# AD/4 TEST PROGRAM






AD/4 TEST PROGRAM CONTINUED





AD/4 TEST PROGRAM CONTINUED



{ ENTERED FROM INTERRUPT 24

AD/4 TEST PROGRAM CONTINUED



	01000	ADRG	01000	START AT 01000
1				
2 *				
3 *		AD/4 TEST		
4 *		WILL TRANSMIT FIVE DIFFERENT AD/4		
5 *		COMMAND LISTS TO THE AD/4		
6 *		COMMAND		
7 *		UNDER SWITCH CONTROL		
8 *				
9		EPD 020276600		
10		EPD 020276700		
11	01000	LDA TRP24		SET UP INTERRUPT
12	01001	STA 024		LOCATION 24
13	01002	LDA TRP33		SET UP CONSOLE
14	01003	STA 033		INT 033
15	01004	0020002		ENABLE INT SYS
16	01005	0 224 0040		CHK SW1
17	01006	0 0 03 01022		
18	01007	0 224 0020		CHK SW2
19	01010	0 0 03 01026		
20	01011	0 224 0010		CHK SW3
21	01012	0 0 03 01032		
22	01013	0 224 0004		CHK SW4
23	01014	0 0 03 01036		
24	01015	0 224 0002		CHK SW5
25	01016	0 0 03 01042		
26	01017	0 0 10 00000		IN CASE A PATCH IS NEEDED
27	01020	0 0 01 01000		L99P ALSO LOC 033
28	01021	0 0 03 01062		L9C 024
29 *				
30 *		SUBROUTINES FOR EACH LIST		
31 *				
32	01022	0 0 00 00000	PZE 0	TRANSMIT LIST 1
33	01023	0 0 03 01066	BRM --> SETUP	
34	01024	0 0 09 02100	PZE BUF1	
35	01025	0 0 41 01022	BRR SUB1	
36	01026	0 0 00 00000	PZE 0	
37	01027	0 0 03 01066	BRM SETUP	
38	01030	0 0 00 02200	PZE BUF2	



01031	0 0 41	01026	BRR	SUB2	
01032	0 0 00	00000	PZE	0	
01033	0 0 03	01066	BRM	SETUP	
01034	0 0 00	02300	PZE	BUF3	
01035	0 0 41	01032	BRR	SUB3	
01036	0 0 00	00000	PZE	0	
01037	0 0 03	01066	BRM	SETUP	
01040	0 0 00	02400	PZE	BUF4	
01041	0 0 41	01036	BRR	SUB4	
01042	0 0 00	00000	PZE	0	
01043	0 0 03	01066	BRM	SETUP	
01044	0 0 00	02500	PZE	BUF5	
01045	0 0 41	01042	BRR	SUB5	
52 *			WAIT L00P		
53 *					
54 *					
55 FLG			PZE	0	FLAG TO COMMUNICATE
56 WAIT			PZE	0	WITH INTRPT RINE
57			STZ	FLG	SET FLG>0
58			NOP		
59			E6M2	2	READ CIU ADRS CNTR
60			PIN	PNTR	
61			LDB	PNTR	
62			SKN	FLG	SEE IF INT 024 YET
63			BRU	WAIT+2	NO
64			NOP		YES
65			BRM	SW61ST	TEST SW6
66			BRR	WAIT	
67 *					
68 *					
69 *					
70 G9					
71			PZE	0	
72			SKR	FLG	SET FLG NEG
73			NOP		
74 *			BRC	*G9	CLEAR INTRPT + RET
75 *					
76 *					SETUP ROUTINE TO XMIT DATA

01066	0 0 00 00000	77 SETUP	PZE	0	
01067	0 0 71 01066	78	MP0	SETUP	
01070	0 0 16 01066	79	LDA	*SETUP	
01071	0 0 76 01117	80	STA	PNTR	ADRS OF LIST
01072	1 0 16 01117	81	LDA	*PNTR	WORD COUNT
01072	0 0 46 01120	82	SKG	ZER0	
01074	0 0 41 01066	83	BRR	SETUP	RETURN IF LE ZER0
01075	0 0 76 01121	84	STA	WC	WORD COUNT
01076	0 0 13 01122	85	MRG	M2	CREATE INDEX REG LOAD
01077	1 40 7 0100	86	COPY	(5,1)	PUT IN X1
01100	0 0 16 01117	87	LDA	PNTR	
01101	0 0 13 01123	88	MRG	X1	CREAT INDRCT INDEXED
01102	0 0 76 01117	89	STA	PNTR	REF
01103	1 0 26 01117	90	LDP	*PNTR	LOAD 2 WORDS OF LIST
01104	0 1 75 60000	91	STD	BUFFER,1	STORE IN BUFFER
01105	0 1 57 01103	92	BRX	*-2,1	LOOP UNTIL DONE
01106	0 2 02 76702	93	EOM2	2	DISCONNECT CIU
01107	0 0 31 01124	94	P0T	STPIT	
01110	0 2 02 76602	95	EOM1	2	OUTPUT WORD COUNT
01111	0 0 31 01121	96	P0T	WC	
01112	0 2 02 76702	97	EOM2	2	OUTPUT CNTRL + ADRS
01113	0 0 31 01125	98	P0T	BUFADR	
01114	0 0 03 01047	99	BRM	WAIT	WAIT FOR INTRPT
01115	0 0 10 00000	100	NBP		
01116	0 0 41 01066	101	BRR	SETUP	RETURN
01117	0 0 00 00000	102	PZE	0	
01120	0 0 00 00000	103	PZE	0	
01121	0 0 00 00000	104	PZE	0	
01122	1 3 76 00000	105	STA	*0,3	INDX INCR>-2
01123	0 1 00 00000	106	HLT	0,1	INDX REG 1
01124	1 0 00 00000	107	STPIT	*0	DISC CIU P0TW0RD
01125	0 2 00 60001	108	BUFADR	BUFFER+1,2	CIU ADRS P0TW0RD
		109 *			
		110 *	SWITCH 6 TEST		
		111 *			
01126	0 0 00 00000	112	SW6TST		
01127	0 224 0001	113	PZE	0	
01130	0 0 01 01127	114	SWT	001	LOOP IF
			BRU	*-1	SWITCH 6 0N



01131	0 0 10 00000	115	NOP	
01132	0 0 41 01126	116	BRR	SW61ST
		117 *		
		118 *	SET CONSOLE INTRPT 033	
		119 *		
00033		120	ARG	033
00033	0 0 01 01000	121	BRU	STRT
		122 *		
		123 *	SET FIVE BUFFERS EMPTY	
		124 *		
02100		125	ARG	02100
02100	0 0 00 00000	126	PZE	0
02200		127	ARG	02200
02200	0 0 00 00000	128	PZE	0
02300		129	ARG	02300
02300	0 0 00 00000	130	PZE	0
02400		131	ARG	02400
02400	0 0 00 00000	132	PZE	0
02500		133	ARG	02500
02500	0 0 00 00000	134	PZE	0
		135 *	OUTPUT BUFFER AREA	
		136 *		
		137 *		
60000		138	ARG	060000
60000		139	RES	0100
		140 *	AN AD/4 REGISTER READ/WRITE ROUTINE	
		141 *		
		142 *		
02100		143	ARG	02100
02100	0 0 00 00004	144	PZE	END1-\$
02101	0 0 00 01022	145	PZE	01022
02102	0 0 00 06223	146	PZE	06223
02103	0 0 00 01426	147	PZE	01426
02104	25252525	148	DATA	025252525
		149 *		
		150 *	AN AD/4 ADC READ ROUTINE	
		151 *		
02200		152	ARG	02200
02200	0 0 00 00013	153	PZE	END2-\$
02201	0 0 00 01022	154	PZE	01022
02202	0 0 00 06220	155	PZE	06220
02203	0 0 00 02444	156	PZE	02444
02204	0 0 00 01022	157	PZE	01022

DATE

02205	0 0 00 06220	158	PZE	06220
02206	0 0 00 03447	159	PZE	03447
02207	25252525	160	DATA	025252525,025252525,025252525
02210	25252525			
02211	25252525			
02212	25252525			
02213	25252525			
	00001000			
		161	END2	DATA 025252525
		162	END	SIRT

APPENDIX B

AD/4 - SDS/9300 DISCRETES  
CHECK OUT PROGRAM

## AD/4 - SDS/9300 DISCRETES CHECK OUT PROGRAM

### PURPOSE

This program writes a 16 bit word into the AD/4 control register 0 and reads back a 16 bit word from the AD/4 sense line register 0. This is accomplished by the SDS/9300 via the direct memory access ports and the remote hybrid interface. The word written and the word read back to the SDS/9300 should be equal if the AD/4 logic board is patched so that DGC 1 goes to DGS 1, DGC 2 to DGS 2, etc.

Execution of the program automatically results in a test of all bit patterns between  $0_8$  and  $77776_8$ . If an error is detected the 9300's B-register display will blink off-and-on 25 times and the next bit pattern will be tested. In addition to blinking the B-register an error message is printed on the TTY. To examine the error condition the program must be stopped and the contents of location 60005 (what was written) compared to location 60015 (what was read back).

### USAGE

The program has three options, all of which are accessed by control panel sense switches. These options provide an unconditional program pause, a pause if error is detected and a bypass of TTY output.

Specifically the options and their usage are as follows:

SS3	ON	Pause if read $\neq$ write (pauses at 60130)
	OFF	Continue
SS5	ON	Bypass TTY error message
	OFF	Print TTY error message
SS6	ON	Program unconditional pause (pauses in a loop at 60001 to 60002)
	OFF	Continue



To load the "binary deck" the user should follow these steps. First, put binary deck on back of Utility Library Program and load card reader. Second, on the computer console;

1. Press Idle.
2. Press Reset (then Press Load on card reader).
3. Press Clear Flags and Clear together.
4. Press Reset.
5. Press Run.
6. Press SS4.
7. Press Cards.

To execute the program do the following:


1. Press Idle.
2. Press Reset.
3. Enter BRU 60000<sub>8</sub> in the accumulator.
4. Press Run.

To use the Utility Library Program for displaying data locations do the following:

1. Press Idle.
2. Press Reset.
3. Press Run.
4. Press INT32.
5. On the keyboard enter SNAP---XXXXX, where XXXXX is the location to be displayed.

To re-enter the test program at any time after using the Utility Library Program repeat the steps required for program execution (as shown above).

# AD/4 - SDS/9300 DISCRETES CHECK OUT PROGRAM





META9300 SIMULATOR

RIM

1 \* WRITE AD4 CONTRL REG 0 AND READ BACK AD4 SENSE LINE REG 0

60000 0 0 71 70003 2 START ADDR 060000

60000 0 0 220002 3 EIR

60001 0 0 224 0001 4 SWT 01

60002 0 0 01 60001 5 BRU #+1

60003 0 0 10 00000 6 NGP

60004 0 0 71 70003 7 INCR MP0 070003

60005 0 0 71 70005 8 MP0 070005

60006 0 0 16 70005 9 LDA 070005

60007 0 0 45 60006 10 SKE MAX

60010 0 0 01 60016 11 BRU RFR

60011 0 0 16 70016 12 LDA =000000

60012 0 0 76 70003 13 STA 070003

60013 0 0 76 70005 14 STA 070005

60014 0 0 10 00000 15 NGP

60015 0 0 10 00000 16 NGP

60016 0 0 16 60004 17 REVR LDA INT1

60017 0 0 76 00024 18 STA 024

60020 20276602 19 DATA 020276602

60021 0 0 31 66000 20 PGT ACN

60022 20276702 21 DATA 020276702

60023 0 0 31 66001 22 PGT SADDW

60024 0 0 01 60024 23 BRU #

60025 0 0 57 60026 24 BRC #+1

60026 0 0 16 66005 25 LDA INT2

60027 0 0 76 00024 26 STA 024

60030 20276602 27 DATA 020276602

60031 0 0 31 66002 28 PGT ACN

60032 20276702 29 DATA 020276702

60033 0 0 31 66003 30 PGT SADDR

60034 0 0 01 60034 31 BRU #

60035 0 0 57 60036 32 BRC #+1

60036 0 0 10 00000 33 NGP

60037 0 0 10 00000 34 NGP

60038 0 0 16 60004 35 REVR LDA INT1

60039 0 0 76 00024 36 STA 024

60040 20276602 37 DATA 020276602

60041 0 0 31 66000 38 PGT ACN

60042 20276702 39 DATA 020276702

60043 0 0 31 66001 40 PGT SADDW

60044 0 0 01 60024 41 BRU #

60045 0 0 57 60026 42 BRC #+1

60046 0 0 16 66005 43 LDA INT2

60047 0 0 76 00024 44 STA 024

60048 20276602 45 DATA 020276602

60049 0 0 31 66002 46 PGT ACN

60050 20276702 47 DATA 020276702

60051 0 0 31 66003 48 PGT SADDR

60052 0 0 01 60034 49 BRU #

60053 0 0 57 60036 50 BRC #+1

```

*****
35 ***** WRITEB+5 TEST FOR WRITE EQUAL READ *****
36 LDA LDA 0 0 16 70005
37 SKE SKE 0 0 45 70015
38 BRU BRU 0 0 01 60044
39 PRINT PRINT 0 0 01 60044
40 START START 0 0 01 60000
41 N9P N9P 0 0 10 00000
42 N8P N8P 0 0 10 00000
*****
43 PRINT SMT 02 USF SSW 5 TO STOP BLINKING LIGHTS
44 BRU BLINK BLINK B REGISTER
45 BRU TYPE TYPE ERROR MESSAGE AND BLIK B REG
46 TYPE *0,1,4
47 E9M 014240
48 POT AMSC
49 CAT 0
50 BRU 4-1
51 AMSC MSG-040000
52 MSG TEXT 40, ERROR IN A04 DISCRETES
*****
53 ***** INITIALIZE LOOP COUNTER *****
54 BLINK LDA =00000
55 STA L88PS
56 L88P =077777
57 LDA =000000
58 STA L8NS
59 LDA =07777
60 L8N
61 N8P
62 N8P
63 N8P
64 N8P

```

60102	0 0 71 66010	MP0	L0NS	
60103	0 0 45 66010	SKE	L0NS	
60104	0 0 01 60075	BRU	L0N	
60105	0 0 14 70016	LDB	=000000	BLINK B REGISTER 9FF
60106	0 0 16 70016	LDA	=000000	
60107	0 0 76 66011	STA	L0FFS	
60110	0 0 16 70020	LDA	=07777	
60111	0 0 10 00000	N0P		
60112	0 0 10 00000	N0P		
60113	0 0 10 00000	N0P		
60114	0 0 10 00000	N0P		
60115	0 0 10 00000	N0P		
60116	0 0 71 66011	MP0	L0FFS	
60117	0 0 45 66011	SKE	L0FFS	
60120	0 0 01 60111	BRU	L0FF	
60121	0 0 71 66007	MP0	L09PS	
60122	0 0 16 70021	LDA	=025	MAXIMUM COUNT
60123	0 0 45 66007	SKE	L09PS	
60124	0 0 01 60071	BRU	L00P	BLINK L00P N0T FINISHED
60125	0 0 10 00000	N0P		
60126	0 0 10 00000	N0P		
60127	0 0 10 00000	N0P		
60130	0 224 0010	SWT	010	USE SSW 3 FOR AUTO STOP AT ERROR
60131	0 0 01 60130	BRU	\$-1	
60132	0 0 10 00000	N0P		
60133	0 0 01 60000	BRU	START	BLINK L00P IS FINISHED
66000		ARG	066000	DATA FOR PROGRAM
66000	00000006	DATA	06	WORD COUNT FOR WRITE
66001	20070000	DATA	020070000	STARTING ADDRESS FOR WRITE
66002	00000006	DATA	06	WORD COUNT FOR READ
66003	20070010	DATA	020070010	STARTING ADDRESS FOR READ
66004	0 0 01 60025	INT1	ENDW	INTERPT RETURN FROM TRAP TO 24
66005	0 0 01 60035	INT2	ENDR	INTERPT RETURN FROM TRAP TO 24
66006	00077776	DATA	077776	MAXIMUM VALUE 9F CONTROL WORD
66007		RES	01	CURRENT L00P COUNT FOR BLINK LIGHT
66010		RES	01	CYCLES 9F LIGHT 9FF
66011		RES	01	CYCLES 9F LIGHT OFF

70000	00001021	105	WRITEB	ABRG	070000	DATA FOR DMA WRITE
70000	00001021	106	DATA	DATA	01021	WRITE IN IRC
70001	00000020	107	DATA	DATA	020	ANALOG RUN MODE
70002	00001050	108	DATA	DATA	01050	WRITE INTO CLR
70003	00000000	109	DATA	DATA	0000000	FIRST WORD WRITTEN IN CLR
70004	00001050	110	DATA	DATA	01050	WRITE INTO CLR
70005	00000000	111	DATA	DATA	0000000	SECOND WORD WRITTEN INTO CLR
		112	*****			
70010		113	READB	ABRG	070010	DATA FOR DMA READ
70010	00001021	114	DATA	DATA	01021	WRITE INTO IRC
70011	00000020	115	DATA	DATA	020	ANALOG RUN MODE
70012	00001460	116	DATA	DATA	01460	READ SENSE LINES
70013		117	RES	RES	01	FIRST WORD READ ON SENSE LINES
70014	00001460	118	DATA	DATA	01460	READ SENSE LINES
70015		119	RES	RES	01	SECOND WORD READ ON SENSE LINES
		120	END			
70016	00000000					
70017	00077777					
70020	00077777					
70021	00000025					



APPENDIX C

3010 DIAGNOSTIC PROGRAM

## 3010 DIAGNOSTIC PROGRAM

### PURPOSE

The program writes and reads back blocks of 23 words from locations  $FEOO_{16}$  to  $FFCO_{16}$  in 3010 core. Each pass the pattern being transmitted is incremented by one. The pattern is incremented from zero to  $177777_8$  and reset to zero when the high count is reached.

If an error is detected in a block the contents of the 9300 read buffer is printed along with data pattern that was transmitted (see example).

To suppress the compare function set sense switch 1.

Every  $10,000_8$  passes through the blocks  $FEOO_8$  to  $FFCO_8$  a print is made (see example) to indicate that the program is operating. (This may be effectively suppressed by loading  $7777\ 7777_8$  into location STOPC ( $60130_8$ )).

### USAGE

To load the program into memory do the following:

1. Put BKD program loader card in hopper.
2. Ready card reader.
3. On the console, push Idle then Reset.
4. Clear register lights.
5. Hold down Clear and Clear Flags for 1 second.
6. Press Reset, Run, and Cards.
7. Program counter will stop at \_\_\_\_\_ indicating load completed.

To execute the program which has been previously loaded do the following:

1. Press Idle, Reset.
2. With register display set to B, enter  $00160200_8$ .
3. Clear the 3010 interface.
4. Press Run.


To suppress data comparison set sense switch 1. To halt set sense switch 6. To modify block length the following changes must be made.

1. LASTLOC (loc.  $60117_8$ ) must contain  $60040_8 + \text{No. words in the block to be transmitted.}$
2. WC1 (loc.  $60112_8$ ) and WC2 (loc.  $60113_8$ ) must contain  $(\text{No. words transmitted} + 1)_8$ .
3. INCR (loc.  $60114$ ) must contain  $(2 \times \text{No. Words})_8$  in the block to be transmitted. For example - to do a 4 word transfer, enter:

WC1	60112	00000005	$(4_8 + 1_8)$
WCZ	60113	00000005	
INCR	60114	00000010	$(2_8 \times 4_8 = 10)$
LASTLOC	60117	00060044	$(60040_8 + 4_8)$


To change the pattern low count load LCNT (60105) with XXXXXXXX where XXXXXXXX is the desired low count. Note the program normally counts from zero to 00177777.

# SDS/9300 to GE/3010 INTERFACE CHECKOUT PROGRAM





# 9300/3010 INTERFACE PROGRAM CONTINUED



RTM

# 1 \*3010/3300 INTERFACE DIAGNOSTIC PROGRAM

60200	00220002	00200	ADRG	060200	
60201	0 0 224 0020	3	START	ELR	
60202	0 0 0 01 60327	4	SWT	020	SET SS 2 TO WRITE ALT ONES AND ZEROS
		5	BRU	PATSEQ	
60203	0 0 16 60121	6	* LOAD	PATTERN IN WRITE BUFFER (STARTS AT 60001)	
60204	0 0 76 60122	7	LDA	FADD	
60205	0 0 16 60102	8	STA	TEMPA	
60206	0 0 76 60123	9	LDA	PATRN	
60207	1 0 76 60122	10	STA	TEMPP	
60210	0 0 71 60122	11	STA	*TEMPA	
60211	0 224 0020	12	MPG	TEMPA	
60212	0 0 01 60340	13	SWT	020	
60213	0 0 16 60122	14	BRU	ZAO	
60214	0 0 46 60124	15	75BAC	TEMPA	
60215	0 0 01 60217	16	SKG	LADD	
60216	0 0 01 60221	17	BRU	CYCLE	
60217	0 0 16 60123	18	BRU	PCHK	
60220	0 0 01 60207	19	CYCLE	TEMPP	
60221	0 0 71 60102	20	BRU	BACK	
60222	0 0 16 60102	21	MPG	PATRN	
60223	0 0 46 60103	22	LDA	PATRN	
60224	0 0 01 60240	23	SKG	HGNT	
60225	0 0 16 60104	24	BRU	WRITE	
60226	0 0 76 60102	25	LDA	LCNT	
60227	0 0 01 60240	26	STA	PATRN	
		27	BRU	WRITE	
60240	0 0 16 60105	28	*WRITE/READ MEMORY		
60241	0 0 76 00020	29	ADRG	060240	
60242	20276604	30	WRITE	RET1	
60243	0 0 31 60111	31	STA	020	
60244	20276704	32	DATA	00202766Q4	
60245	0 0 31 60107	33	POT	WC1	
60246	0 0 01 60246	34	DATA	0020276704	
60247	0 0 16 60106	35	POT	SA1	
60250	0 0 76 00020	36	BRU	5	
60251	20276604	37	LDA	RET2	
60252	0 0 31 60112	38	STA	020	
60253	20276704	39	DATA	00202766Q4	
60254	0 0 31 60110	40	POT	WC2	
		41	DATA	0020276704	
		42	POT	SA2	

HIGH COUNT REACHED  
GO TO WRITE / READ  
RESET COUNTER TO LOW COUNT

60255	0	0	01	60255	43	BRU	4
60256	0	0	10	00000	44	NBP	
60257	0	224	0001		45	SWI	001 SET SS6 TO HALT
60260	0	0	00	00000	46	HLT	
60261	0	0	01	60271	47	BRU	INCPT
60262	0	0	16	60000	48	INCRM	* INCREMENT THE BLOCK STARTING ADDRESS
60263	0	0	05	60113	49	LDA	WBA
60264	0	0	44	60117	50	ADD	INCR
					51	SKL	MTSP

60265	0	0	01	60310	52	BRU	ARELD	GO TO MEMORY ADDR RELOAD ROUTINE
60266	0	0	76	60000	53	STA	WBA	
60267	0	0	76	60040	54	STA	RBA	
60270	0	0	01	60240	55	BRU	WRITE	
60271	0	224	0040		56	SWI	040	SET SS1 TO SUPPRESS COMPARE AND PRINT
60272	0	0	01	60262	57	BRU	INCRM	
60273	0	0	16	60114	58	CMPAR	LDA	* COMPARE DATA WRITTEN WITH DATA READ
60274	0	0	76	60100	59	STA	WSTA	
60275	0	0	16	60115	60	LDA	RSTA	
60276	0	0	76	60101	61	STA	TRSTA	
60277	1	0	16	60100	62	LDA	*TWSTA	
60300	1	0	45	60101	63	SKE	*TRSTA	
60301	0	0	01	60323	64	BRU	PRINT	
60302	0	0	71	60100	65	MP0	WSTA	
60303	0	0	71	60101	66	MP0	TRSTA	
60304	0	0	16	60101	67	LDA	TRSTA	
60305	0	0	45	60116	68	SKE	LSILBC	QUIT IF LAST LOCATION
60306	0	0	01	60277	69	BRU	CAGN	
60307	0	0	01	60262	70	BRU	INCRM	
60310	0	0	16	60120	71	ARELD	LDA	* MEMORY BLOCK ADDRESS RELOAD
60311	0	0	76	60000	72	STA	WBA	
60312	0	0	76	60040	73	STA	RBA	
60313	0	0	71	60127	74	MP0	PCNIR	
60314	0	0	16	60127	75	LDA	PCNIR	
60315	0	0	45	60130	76	SKE	ST9PC	
60316	0	0	01	60200	77	BRU	START	
60317	0	0	03	02106	78	BRM	02106	
60320	0	0	77	60127	79	STZ	PCNIR	

60321	0 0 71 60127	82	MP0	PCNIR
60322	0 0 01 60200	83	BRU	START
60323	0 0 76 60071	84	* ENTRY TO	UTILITY PRINT ROUTINE
60324	0 0 03 02106	85	PRINT STA	RBA+25
60325	0 0 77 60071	86	BRU	02106
60326	0 0 01 60262	87	STZ	RBA+25
		88	BRU	INCRM
60327	0 0 16 60133	89	* SET INITIAL	PATRN TO ZERO OR ONE
60330	0 0 76 60102	90	PATSEQ LDA	PATRN
60331	0 0 45 60131	91	STA	PATRN
60332	0 0 01 60336	92	SKE	ZEROS
60333	0 0 16 60132	93	BRU	X
60334	0 0 76 60133	94	LDA	ONES
60335	0 0 01 60203	95	STA	PATRN
60336	0 0 77 60133	96	BRU	LOAD
60337	0 0 61 60203	97	STZ	PATRN
		98	BRU	LOAD
60340	0 0 16 60123	99	* ALTERNATE	THE PATRN FROM ONES TO ZEROS
60341	0 0 45 60132	100	ZAG	TEMP
60342	0 0 01 60345	101	SKE	ONES
60343	0 0 77 60123	102	BRU	Z
60344	0 0 01 60213	103	STZ	TEMP
		104	BRU	Z98AC
60345	0 0 16 60132	105	Z	ONES
60346	0 0 76 60123	106	STA	TEMP
60347	0 0 01 60213	107	BRU	Z00AC
60000		108	ASRG	060000
60000	00177000	109	* DATA BUFFER	WRITE
60001		110	WBA	DATA
		111	RES	035
		112		
60040		113	* DATA BUFFER	READ
60040	00177000	114	ASRG	060040
60041		115	RBA	DATA
60076	00060000	116	RES	035
60077	00060040	117	WSA	DATA
		118	RSA	DATA



60100	0 0 00 00000	119	TWSTA	PZE	
60101	0 0 00 00000	120	TRSTA	PZE	
60102	00000001	121	PATRN	DATA	01 00177777
60103	00177777	122	HCNT	DATA	0000000000
60104	00000000	123	LCNT	DATA	005760247
60105	00760247	124	REI1	DATA	005760256
60106	00760256	125	REI2	DATA	020060000
60107	20060000	126	SA1	DATA	020060040
60110	20060040	127	SA2	DATA	030
60111	00000030	128	WC1	DATA	030
60112	00000030	129	WC2	DATA	056
60113	00000056	130	INCR	DATA	060001
60114	00000001	131	WSTA	DATA	060041
60115	00060041	132	RSTA	DATA	060067
60116	00060067	133	LSTL8C	DATA	0177700
60117	00177700	134	MT6P	DATA	0177000
60120	00177000	135	LB5A	DATA	060001
60121	00060001	136	FADD	DATA	
60122	0 0 00 00000	137	TEPPA	PZE	
60123	0 0 00 00000	138	TEPPP	PZE	
60124	00060031	139	LADD	DATA	060031
60125	0 0 00 00000	140	TBSAW	PZE	
60126	0 0 00 00000	141	TBSAR	PZE	
60127	0 0 00 00000	142	PCNIR	PZE	
60130	00040000	143	STEPC	DATA	040000
60131	00000000	144	ZERRS	DATA	000000000
60132	00177777	145	ONES	DATA	000177777
60133	00177777	146	PATRN	DATA	000177777
		147		END	

APPENDIX D

FORTRAN HYBRID SOFTWARE

## FORTRAN HYBRID SOFTWARE

This Appendix contains the real-time software for the STINGER simulation. The code presented here was converted from IBM-7094 MAP into CDC-6600 FORTRAN hybrid. The statements denoted SOFT-T pertain to the software test procedures. The statements denoted SOFT-MOD correct inconsistencies between the FTN. and FTHH. compilers.

## SUBROUTINE FLIGHT

### PURPOSE

This program serves as a driver for the STINGER real-time code. The program initializes parameters, reserves DADIOS equipment and transfers initial conditions to the AD-4.

### DESCRIPTION OF PARAMETERS

(see code)

### SUBROUTINES REQUIRED

- SUBROUTINE ADFOUR
- SUBROUTINE SIMRUN
- SUBROUTINE REALT
- SUBROUTINE BHOLD
- SUBROUTINE RES



# SUBROUTINE FLIGHT

## PROGRAM VARIABLES

MAXBIT	MAXIMUM BITS CONVERTED IN INPUT SENSE LINE
BIT(I)	BIT CONVERSION OF INPUT SENSE LINE
IIN	INPUT SENSE LINE
ICUT	OUTPUT SENSE LINE
	SENSE LINE 0 = 0000000000000001 = 1
	SENSE LINE 1 = 0000000000000010 = 2
	SENSE LINE 2 = 0000000000000100 = 4
	SENSE LINE 3 = 0000000000001000 = 8
	SENSE LINE 4 = 0000000000010000 = 16
	SENSE LINE 5 = 0000000000100000 = 32
	SENSE LINE 6 = 0000000001000000 = 64
	SENSE LINE 7 = 0000000010000000 = 128
	SENSE LINE 8 = 0000000100000000 = 256
LAUNCH(I)	DAC VARIABLES
ADIN(I)	ADC VARIABLES
IWRITE	IF IWRITE = 1, WRITE COMMENTS

REAL MAN(200), MISSED(7), MISS, LAUNCH

INTEGER WMAN

DIMENSION FIN(10), TS(30)

EQUIVALENCE (TS(1), TMS(1)), (MAN(1), XMAN(1)), (MISSED(1), XMISS(1))

EQUIVALENCE (FIN(1), DX), (FIN(2), DY), (FIN(3), DZ), (FIN(4), DT)

EQUIVALENCE (FIN(5), XDOT), (FIN(6), YDOT), (FIN(7), ZDOT)

EQUIVALENCE (FIN(8), XXX), (FIN(9), YYY), (FIN(10), ZZZ)

COMMON/EXTRA/IT1, KCK, ICR2, IOA3, IND, INDEX

COMMON/COMA/LEVEL, IPTS, XXS(50), XDTGO, YDTGO, ZDTGO, RLB, COSE, SPO, RI,

\*GAM, EDOT, THETA, RN,

\* PPX(50), PPY(50), PPZ(50), TIME(50), TMS(30), XDTGMS(30)

\* , YDTGMS(30), ZDTGMS(30), XMAN(4, 50), XMISS(7), NT

\* , XCOMP, YCOMP, ZCOMP, TMA(30), DELTAR(30), VM(30), G, GGG

\* , XDO, YDO, ZDO, DXG, DYG, DZG, S2, S3, S4, S5, XDM(30), YDM(30), ZDM(30),

\*RLBK, SCALEP, F1, F2, F3, G1, G2, G3, XC, YC, ZC, S1, RRR, SR, SPL, CTL, STL,

\*CPL, A1, VTI, XE(30), YE(30), ZE(30), ZALT, NERR, CLA, NPX, NX, CLAA(10),

\*PHO, ARG, AAA, SCALET, TREAL, TMA(30), XTA, YTA, ZTA, SCALEV, QMM(10), QM

\* , SA, CA, VMX(50), VMY(50), VMZ(50)

COMMON/INTCOM/IBIT(60), MAXBIT, IWRITE

COMMON/ZADC1/ADIN(10)

SOFT-MOD

COMMON/ZDAC1/LAUNCH(11)

SOFT-MOD

COMMON/ZODIS2/ICUT

SOFT-MOD

COMMON/ZIDIS2/IIN

SOFT-MOD

LEVEL=7

IT1=1

KCK=-1

ICR2=29

IOA3=0

IND=0

INDEX=0

MAXBIT=16

ICUT=0

IWRITE = 1

DO 3 I=1, MAXBIT

3 IBIT(I)=0

WAIT FOR STATIC CHECK COMPLETE ( BIT 5 )

```

1 CONTINUE
  CALL ADFOUR
  CALL SIMRUN(ISTAT)
  WRITE(6,2000)ISTAT
  IF(ISTAT.GT.0)STOP
  CALL REMARK(17H JOB IN REAL TIME)
  IF(IBIT(5).NE.1)GO TO 1
  IF(IWRITE.EQ.1)WRITE(6,3000)
C
C  MOVE OUTPUT DATA TO DACS
C
  LAUNCH(1)=XDTGO
  LAUNCH(2)=YDTGO
  LAUNCH(3)=ZDTGO
  LAUNCH(4)=RLB
  LAUNCH(5)=COSE
  LAUNCH(6)=SPO
  LAUNCH(7)=R1
  LAUNCH(8)=GAM
  LAUNCH(9)=EDOT
  LAUNCH(10)=THETAL
  LAUNCH(11)=RN
  WRITE(6,5001)(LAUNCH(II),II=1,11)
5001 FORMAT(8H LAUNCH=,11F5.2)
C
C  SEND STATUS BIT TO AD/4 INDICATING ICS SENT ( BIT 4 )
C
  IOUT=16
  CALL ADFOUR
C
C  WAIT FOR RAMP UP SIGNAL FROM AD/4 (BIT 6)
C
2 CONTINUE
  CALL ADFOUR
  IF(IBIT(6).NE.1)GO TO 2
  IF(IWRITE.EQ.1)WRITE(6,4000)
C
  CALL REALT
  CALL BHOLD
2000 FORMAT(13H REAL TIME STATUS=,02)
3000 FORMAT(22H STATIC CHECK COMPLETE)
4000 FORMAT(23H RAMP UP SIGNAL RECEIVED)
  RETURN
  END

```

SOFT-T

SOFT-T  
SOFT-T

SOFT-T

SOFT-T

SOFT-T

## SUBROUTINE REALT

### PURPOSE

This program contains the real-time digital computer computations required for the STINGER simulation. Program inputs are received from the AD-4 via DADIOS ADCs and discretes. The program outputs are transmitted to the AD-4 via DADIOS DACs and discretes.

### SUBROUTINES REQUIRED

- SUBROUTINE SIMSTOP
- SUBROUTINE SIMHOLD
- SUBROUTINE ADFOUR
- SUBROUTINE SIMIDLE

SUBROUTINE REALT

REAL MAN(200), MISSED(7), MISS, LAUNCH

INTEGER WMAN

DIMENSION FIN(10), TS(30)

EQUIVALENCE (TS(1), TMA(1)), (MAN(1), XMAN(1)), (MISSED(1), XMISS(1))

EQUIVALENCE (FIN(1), DX), (FIN(2), DY), (FIN(3), DZ), (FIN(4), DT)

EQUIVALENCE (FIN(5), XDOT), (FIN(6), YDOT), (FIN(7), ZDOT)

EQUIVALENCE (FIN(8), XXX), (FIN(9), YYY), (FIN(10), ZZZ)

COMMON/EXTRA/IT1, KCK, ICR2, IDA3, IND, INDEX

COMMON/COMA/LEVEL, IPTS, XXS(50), XDTG0, YDTG0, ZDTG0, RL3, COSE, SPO, RI,

\*SAM, EDOT, THETA, RN,

\* PPX(50), PPY(50), PPZ(50), TIME(50), TMA(30), XDTGMS(30)

\* YDTGMS(30), ZDTGMS(30), XMAN(4,50), XMISS(7), NT

\* XCOMP, YCOMP, ZCOMP, TMA(30), DELTAR(30), VM(30), G, GGG

\* XDO, YDO, ZDO, DXG, DYG, DZG, S2, S3, S4, S5, XDM(30), YDM(30), ZDM(30),

\*RLBK, SCALEP, F1, F2, F3, G1, G2, G3, XC, YC, ZC, S1, RRR, SR, SPL, CTL, STL,

\*CPL, A1, VTI, XE(30), YE(30), ZE(30), ZALT, NERR, CLA, NPX, NK, CLAA(10),

\*PHO, ARG, AAA, SCALET, TREAL, TMA(30), XTA, YTA, ZTA, SCALEV, QMM(10), QM

\* SA, CA, VMX(50), VMY(50), VMZ(50)

COMMON/INTCOM/IBIT(60), MAXBIT, INWRITE

COMMON/ZAGC1/ADIN(10)

SOFT-MOD

COMMON/ZOAC1/LAUNCH(11)

SOFT-MOD

COMMON/ZIDIS2/IIN

SOFT-MOD

COMMON/ZODIS2/IOUT

SOFT-MOD

C

C WAIT FOR FRAME SYNC FROM IRSS ( BIT 8)

1001 CALL ADFOUR

SOFT-T

IF (IBIT(8).NE.1) GO TO 1000

WMAN=0

MAX=50

C

C READ ADCS

C

DO 2 I=1,10

2 FIN(I)=ADIN(2)

CALL ADFOUR

SOFT-T

C

SCALE ADCS

C

DO 3 I=1,3

3 FIN(I)=FIN(I)\*SCALEP

IF (XXS(INDEX+1).GT.DX) GO TO 5

C

GO TO 3 CHANNEL MODE

C

OUTPUT BIT 3 TO AD/4

C

ICUT=8

CALL ADFOUR

SOFT-T

C

PPX(INDEX+1)=FIN(1)

PPY(INDEX+1)=FIN(2)

PPZ(INDEX+1)=FIN(3)

TIME(INDEX+1)=FIN(4)

VMX(INDEX+1)=FIN(5)

VMY(INDEX+1)=FIN(6)

VMZ(INDEX+1)=FIN(7)



WMAN=7  
IOA3=1

C  
C  
C  
CKMISS

5 CONTINUE  
IF (DT/10.0.LE.0) GO TO 10  
SKK=GGG+1.0  
KCK=1  
MISS=DX\*XDOT+DY\*YDOT+DZ\*ZDOT  
IF (MISS.LE.0.0) GO TO 10  
MISSED(1)=FIN(1)  
MISSED(2)=FIN(2)  
MISSED(3)=FIN(3)  
MISSED(4)=FIN(4)  
MISSED(5)=FIN(5)  
MISSED(6)=FIN(6)  
MISSED(7)=FIN(7)

3000 CONTINUE

C  
C  
C  
SYSTEM HOLD (SEND BIT 7 TO AD/4)  
IOUT=128  
CALL ADFOUR

SOFT-T

C  
C  
C  
RETURN TO BATCH JOB

C  
C  
CALL SIMSTOP  
RETURN

SOFT-T

C  
C  
CKTIME

10 CONTINUE  
IF (LEVEL.GT.0) GO TO 1000  
IF (DT.LT.TS(1)) GO TO 1000  
LEVEL=0  
20 CONTINUE  
IF (DT.LE.TS(30-ICR2)) GO TO 30  
IT1=IT1+1  
IF (IT1.EQ.NT) GO TO 25  
IF (ICR2.LE.1) GO TO 25  
ICR2=ICR2-1  
GO TO 20

25 CONTINUE  
LEVEL=7  
GO TO 1000

C  
30 CONTINUE  
IT2=IT1+1  
IF (WMAN.EQ.0) GO TO 100  
IND=IND+1  
IF (MAX.LT.IND) GO TO 100  
MAN(4\*IND-3)=DT

100 CONTINUE

C  
C  
C  
CALC

DIV=TS(IT2)-TS(IT1)  
RATIO=(DT-TS(IT1))/DIV

```

XCOMP=XDTGMS(IT1)+RATIO*(XDTGMS(IT2)-XDTGMS(IT1))
XC=XDM(IT1)+RATIO*(XDM(IT2)-XDM(IT1))
YCOMP=YDTGMS(IT1)+RATIO*(YDTGMS(IT2)-YDTGMS(IT1))
YC=YDM(IT1)+RATIO*(YDM(IT2)-YDM(IT1))
ZCOMP=ZDTGMS(IT1)+RATIO*(ZDTGMS(IT2)-ZDTGMS(IT1))
ZC=ZDM(IT1)+RATIO*(ZDM(IT2)-ZDM(IT1))
TREAL=DT*SCALET
IF(KCK.LT.0)SSK=1.0+GGG*TREAL/G
IF(IGA3.GT.0)GO TO 200
AAA=0.003894*ZALT+1116.89
VTI=SQRT(XC*XC+YC*YC+ZC*ZC)
IF(VTI.LT.338.0)GO TO 200
ARG=0.00003*ZALT
PHO=0.00237892*EXP(ARG)
QM=VTI/AAA
NPX=2
NX=5
CALL INTERP(QM,QNM,CLAA,NX,NPX,CLA,NERR)
CALL INTERP(TREAL,TMA,XE,NT,NPX,XTA,NERR)
CALL INTERP(TREAL,TMA,YE,NT,NPX,YTA,NERR)
CALL INTERP(TREAL,TMA,ZE,NT,NPX,ZTA,NERR)
A1=XTA*XTA+YTA*YTA+ZTA*ZTA
A1=0.01745329*4.637884242*SQRT(A1)/(PHO*VTI*VTI*CLA)
SA=SIN(A1)
CA=COS(A1)
XXX=XXX*20475.0/SKK
YYY=YYY*20475.0/SKK
ZZZ=ZZZ*20475.0/SKK
RRR=XXX*XXX+YYY*YYY+ZZZ*ZZZ
RRR=VTI*SQRT(RRR)
F1=S2*XXX-YYY*SPL+S3*ZZZ
F2=XXX*S4+YYY*CPL+ZZZ*S5
F3=CTL*ZZZ-STL*XXX
SR=SQRT(XC*XC+YC*YC)
S1=CA+S4/SR*ZC
G1=S1*XC
G2=S1*YC
G3=ZC*CA-SA*SR
E111=(F1*G1+F2*G2+F3*G3)/RRR
COSE=1.0-E111*E111
RLB=SQRT(COSE)
RLB=RLB*RLBK/SCALET
COSE=E111/1.02375
RC1=SQRT(F1*F1+F2*F2)
RC1=F2/RC1
RCB=ACOS(RC1)
RCX=-RC1
RCY=-SIN(RCB)
IF(F1.GE.0.0)RCY=-RCY
F11=(F2*G3-F3*G2)/VTI
F22=(G1*F3-G3*F1)/VTI
F33=(G2*F1-G1*F2)/VTI
FCR=SQRT(F11*F11+F22*F22+F33*F33)
G11=F11*RCX
G22=F22*RCY
C111=(G11+G22)/FCR
T111=ACOS(C111)

```

IF(F33.GE.0.0)GO TO 155  
IF(T111.LT.1.570796326)GO TO 156  
TRP=1.570796326+T111  
GO TO 159

155 TRP=1.570796326-T111  
GO TO 159

156 TRP=T111-4.71233393

159 SPO=TRP/SCALET

210 CONTINUE

C  
C  
C

HERE  
IF(WMAN.EQ.0)GO TO 2000  
IF(MAX.LE.IND)GO TO 2000  
MAN(4\*IND-2)=XCOMP  
MAN(4\*IND-1)=YCOMP  
MAN(4\*IND)=ZCOMP  
INDEX=INDEX+1  
IF(INDEX.GT.IPTS)GO TO 3000

2000 CONTINUE

C  
C  
C

UPDATE THE DACS


LAUNCH(1)=XCOMP  
LAUNCH(2)=YCOMP  
LAUNCH(3)=ZCOMP  
LAUNCH(4)=RLB  
LAUNCH(5)=COSE  
LAUNCH(6)=SPO  
LAUNCH(7)=RI  
LAUNCH(8)=GAM  
LAUNCH(9)=EDOT  
LAUNCH(10)=THETAL  
LAUNCH(11)=RN  
WRITE(6,5001)(LAUNCH(II),I=1,11)  
5001 FORMAT(8H LAUNCH=,11F5.2)  
1000 CALL SIMIOLE  
GO TO 1001  
END

SOFT-T


SOFT-T


SOFT-T


# SUBROUTINES FLIGHT AND REALT


























H

INTERP(TREAL, TMA, ZE, NT, NPX, ZTA, NERR)

$$A1 = XTA^2 + YTA^2 + ZTA^2$$


$$A1 = 0.01745329 * 4.637084242 * \sqrt{A1} / (PHO * VTI^2 * CLA)$$


SA = SIN(A1)  
 CA = COS(A1)  
 XXX = XXX \* 20475.0 / SKK  
 YYY = YYY \* 20475.0 / SKK  
 ZZZ = ZZZ \* 20475.0 / SKK  
 RRR = XXX<sup>2</sup> + YYY<sup>2</sup> + ZZZ<sup>2</sup>  
 RRR = VTI \*  $\sqrt{RRR}$   
 F1 = S2 \* XXX - YYY \* SPL + S3 \* ZZZ  
 F2 = XXX \* S4 + YYY \* CPL + ZZZ \* S5  
 F3 = CTL \* ZZZ - STL \* XXX  
 SR =  $\sqrt{XC^2 + YC^2}$   
 S1 = CA + (SA / SR) \* ZC  
 G1 = S1 \* XC

G2 = S1 \* YC  
 G3 = ZC \* CA - SA \* SR  
 E111 = (F1 \* G1 + F2 \* G2 + F3 \* G3) / RRR  
 COSE = 1 - E111  
 RLB = COSE  
 RLB = RLB \* RLBK / SCALET  
 COSE = E111 / 1.02375  
 RC1 =  $\sqrt{F1^2 + F2^2}$   
 RC1 = F2 / RC1  
 RCB = ARCCOS(RC1)  
 RCX = -RC1  
 RCY = -SIN(RCB)

I







## SUBROUTINE BITS

### PURPOSE

The 16 bit discrete word sent by the AD-4 to the CDC-6600 is converted into bits by this program. The discrete word is periodically reconverted and updated in a COMMON block. On completion of a conversion the high order bit is stored in IBIT(1).

### SUBROUTINES REQUIRED

- SUBROUTINE SIMIDLE

SUBROUTINE BITS  
COMMON/ZIDIS2/IIN  
COMMON/INTCOM/IBIT(60),MAXBIT

SOFT-MOD

C  
C  
C  
CONVERT IWORD TO BITS

INTEGER OLDNUM

DO 1 I=1,MAXBIT

1 IBIT(I)=0

OLDNUM=IIN

I=1

2 NEWNUM=OLDNUM/2

IBIT(I)=OLDNUM-2\*NEWNUM

OLDNUM=NEWNUM

I=I+1

IF (OLDNUM.EQ.0.OR.I.LT.MAXBIT) GO TO 2

CALL SIMIDLE

RETURN

END

SOFT-T



## SUBROUTINE ADFOUR AND ADC

### PURPOSE

These programs together simulate AD-4 functions required by the STINGER real-time simulation. The programs functions as a table-look-up of ADC data required by SUBROUTINE REALT and SUBROUTINE FLIGHT. In addition, the programs transfers discrete data to the aforementioned subroutines.

### SUBROUTINES REQUIRED

- o SUBROUTINE BITS
- o SUBROUTINE ADC

SUBROUTINE ADFOUR	SOFT-T
REAL MAN(200), MISSED(7), MISS, LAUNCH	SOFT-T
INTEGER WMAN	SOFT-T
DIMENSION FIN(10), TS(30)	SOFT-T
EQUIVALENCE (TS(1), TMA(1)), (MAN(1), XMAN(1)), (MISSED(1), XMISS(1))	
EQUIVALENCE (FIN(1), DX), (FIN(2), DY), (FIN(3), DZ), (FIN(4), DT)	SOFT-T
EQUIVALENCE (FIN(5), XDOT), (FIN(6), YDOT), (FIN(7), ZDOT)	SOFT-T
EQUIVALENCE (FIN(8), XXX), (FIN(9), YYY), (FIN(10), ZZZ)	SOFT-T
COMMON/COMA/LEVEL, IPTS, XXS(50), XDTGO, YDTGO, ZDTGO, RLB, COSE, SPO, RI,	SOFT-T
* GAM, EDOT, THETA, RN,	SOFT-T
*                   RPX(50), PPY(50), PPZ(50), TIME(50), TMA(30), XDTGMS(30)	SOFT-T
*                   , YDTGMS(30), ZDTGMS(30), XMAN(4,50), XMISS(7), NT	SOFT-T
*                   , XCOMP, YCOMP, ZCOMP, TMA(30), DELTAR(30), VM(30), G, GGG	SOFT-T
* , XDO, YDO, ZDO, DXG, DYG, DZG, S2, S3, S4, S5, XDM(30), YDM(30), ZDM(30),	SOFT-T
* RLBK, SCALEP, F1, F2, F3, G1, G2, G3, XC, YC, ZC, S1, RRR, SR, SPL, CTL, STL,	SOFT-T
* CPL, A1, VTI, XE(30), YE(30), ZE(30), ZALT, NERR, CLA, NPX, NX, CLAA(10),	SOFT-T
* PHO, ARG, AAA, SCALET, TREAL, TMA(30), XTA, YTA, ZTA, SCALEV, QMM(10), QM	SOFT-T
* , SA, CA, VMX(50), VMY(50), VMZ(50)	SOFT-T
COMMON/ZADCL/ADIN(10)	SOFT-MOD
COMMON/ZDAC1/LAUNCH(11)	SOFT-MOD
COMMON/ZODIS2/IOU	SOFT-MOD
COMMON/ZIDIS2/IIN	SOFT-MOD
DATA ITIME/-100/	SOFT-T
ITIME=ITIME+1	SOFT-T
C    STATIC CHECK OK	SOFT-T
IF(ITIME.EQ.-50) IIN=32	SOFT-T
C    SEND ICS	SOFT-T
IF(ITIME.EQ.-50) CALL ADC(ITIME)	SOFT-T
C    RAMP UP SIGNAL	SOFT-T
IF(ITIME.EQ.-40) IIN=64	SOFT-T
C	SOFT-T
CALL BITS	SOFT-T
C    UPDATE ADC	SOFT-T
CALL ADC(ITIME)	SOFT-T
RETURN	SOFT-T
END	SOFT-T

	SUBROUTINE ADC(ITIME)	SOFT-T
	REAL MAN(200), MISSED(7), MISS, LAUNCH	SOFT-T
	INTEGER WMAN	SOFT-T
	DIMENSION FIN(10), TS(30)	SOFT-T
	EQUIVALENCE (TS(1), TMS(1)), (MAN(1), XMAN(1)), (MISSED(1), XMISS(1))	
	EQUIVALENCE (FIN(1), DX), (FIN(2), DY), (FIN(3), DZ), (FIN(4), DT)	SOFT-T
	EQUIVALENCE (FIN(5), XDOT), (FIN(6), YDOT), (FIN(7), ZDOT)	SOFT-T
	EQUIVALENCE (FIN(8), XXX), (FIN(9), YYY), (FIN(10), ZZZ)	SOFT-T
	COMMON/COMA/LEVEL, IPTS, XXS(50), XDTGO, YDTGO, ZDTGO, RLB, COSE, SPO, RI,	SOFT-T
	*GAM, EDOT, THETA, RN,	SOFT-T
	* PPX(50), PPY(50), PPZ(50), TIME(50), TMS(30), XDTGMS(30)	SOFT-T
	* YDTGMS(30), ZDTGMS(30), XMAN(4,50), XMISS(7), NT	SOFT-T
	* XCOMP, YCOMP, ZCOMP, TAMA(30), DELTAR(30), VM(30), G, GGG	SOFT-T
	* XDO, YDO, ZDO, DXG, DYG, DZG, S2, S3, S4, S5, XDM(30), YDM(30), ZDM(30),	SOFT-T
	*RLBK, SCALEP, F1, F2, F3, G1, G2, G3, XC, YC, ZC, S1, RRR, SR, SPL, CTL, STL,	SOFT-T
	*CPL, A1, VTI, XE(30), YE(30), ZE(30), ZALT, NERR, CLA, NPX, NX, CLAA(10),	SOFT-T
	*PHO, ARG, AAA, SCALET, TREAL, TMA(30), XTA, YTA, ZTA, SCALEV, QMM(10), QM	SOFT-T
	* SA, CA, VMX(50), VMY(50), VMZ(50)	SOFT-T
	COMMON/ZADC1/ADIN(10)	SOFT-MOD
	COMMON/ZDAC1/LAUNCH(11)	SOFT-MOD
	COMMON/ZODIS2/IOUT	SOFT-MOD
	COMMON/ZIDIS2/IIN	SOFT-MOD
C		SOFT-T
C	PROGRAM TO UPDATE ADC INPUTS	SOFT-T
C		SOFT-T
	DIMENSION A(10,500)	SOFT-T
	IF(ITIME.EQ.-50) KTIME=1	SOFT-T
	IF(ITIME.GE.0) KTIME=KTIME+1	SOFT-T
	IF(KTIME.GT.500) WRITE(6,1000)	SOFT-T
C		SOFT-T
C		SOFT-T
C		SOFT-T
C	DEFINE THE A ARRAY HERE	SOFT-T
	IF (KTIME.GE.2) GO TO 101	
	DO 50 I=1,10	SOFT-T
	DO 50 KDUM=1,500	SOFT-T
	A(KDUM,I)=0.0	SOFT-T
	50 CONTINUE	SOFT-T
	101 CONTINUE	
C		SOFT-T
	DO 100 I=1,10	SOFT-T
	ADIN(I)=A(KTIME,I)	SOFT-T
	100 CONTINUE	SOFT-T
	RETURN	SOFT-T
	1000 FORMAT(15H ERROR IN KTIME)	SOFT-T
	END	SOFT-T



LINE SIMSTOP 74/74 OPT=1

FTN 4.2+75067

04/11/75

SUBROUTINE SIMSTOP  
RETURN  
END

SOFT-T  
SOFT-T  
SOFT-T

SUBROUTINE BOLD  
RETURN  
END

SOFT-T  
SOFT-T  
SOFT-T

SUBROUTINE SIMRUN (ISTAT)  
ISTAT=0  
RETURN  
END

SOFT-I  
SOFT-I  
SOFT-I  
SOFT-I

SUBROUTINE SIMIDLE  
RETURN  
END

SOFT-T  
SOFT-T  
SOFT-T



APPENDIX E

DADIOS CHECKOUT PROGRAMS

## DADIOS CHECKOUT PROGRAMS

This appendix contains special programs for pre-real-time checkout. These programs provide a quick method of testing discretetes, DACs and ADCs. Usage of each program is described in the computer code.

```

PROGRAM TRDISI(OUTPUT,HFILE,TAPE6=OUTPUT)
C
C PROGRAM TO INDIVIDUALLY TEST DADIOS DISCRETES FROM AD/4 TO
C CDC/6600. THIS IS ACCOMPLISHED BY PATCHING LOGIC 1 TO THE DESIRED
C AD/4 TRUNK LINES. EACH TIME THE AD/4 PATCHING IS CHANGED THE
C CDC/6600 RECORDS THE BIT PATTERN FOR COMPARISON. A RECORD OF THE
C BIT PATTERNS IS AVAILABLE THROUGH OPERATOR AID OR THE LINE PRINTER
C
C PROGRAM VARIABLES
C IERR ERROR CODE FOR RESERVATION
C 0=NOERROR, GT.0=RESERVATION ERROR
C ISTAT REAL TIME MODE
C 0=IN REAL TIME, ISTAT.GT.0 NOT IN REAL TIME
C IDUM1 DISCRETE WORD TRANSMITTED FROM AD/4 TO CDC/6600
C ICNT1 TIME SINCE LAST BIT WAS CHANGED (SECONDS)
C
C DADIOS PATCHING REQUIREMENTS (ONE OF THE FOLLOWING)
C
C TRUNKING FORTRAN AD/4 LOGIC
C V-50 TO W-50 FOR /IDIS2/1,IIDIS TR00-TR07 AND TR20-TR27
C V-50 TO W-51 FOR /IDIS2/2,IIDIS TR00-TR07 AND TR20-TR27
C V-52 TO W51 FOR /IDIS2/2,IIDIS TR40-TR47 AND TR50-TR67
C V-52 TO W50 FOR /IDIS2/1,IIDIS TR40-TR47 AND TR50-TR67
C
COMMON/INTCOM/ICNT1,IDUM1,ITEMP,IBIT(60)
INTERRUPT(I=1,R=10,F=100000)
COMMON/*IDIS2/2,IIDIS
C
C INITIALIZATION
C
ITEMP=0
CALL RESERVE(IERR)
ICNT1=0
WRITE(6,1000)IERR
IF(IERR.NE.0)STOP
C
C REAL TIME
C
CALL SIMRUN(ISTAT)
WRITE(6,2000)ISTAT
WRITE(6,6000)
WRITE(6,5000)
IF(ISTAT.GT.0)STOP
CALL REMARK(17H JOB IN REAL TIME)
25 CONTINUE
CALL BHOLD
CALL REMARK(15H RETURN TO MAIN)
CALL OCTDIS( 54 BITS,IDUM1)
CALL BITS
WRITE(6,4000)IDUM1,IDUM1,(IBIT(KK),K=1,16),ICNT1
ICNT1=0
CALL SIMCO
GO TO 25
1000 FORMAT(2+HRESERVATION ERROR CODE=,020)
2000 FORMAT(18H REAL TIME STATUS=,020)
4000 FORMAT(5X,010,I10,5X,16I1,I10,* TR=.....*)
5000 FORMAT(*0 OCTAL BASE TEN .....BITS.... TIME*)

```

6000 FORMAT(\*)  
STOP  
END

RECORD OF DATA RECEIVED \*)

SUBROUTINE BITS

C  
C  
C

PROGRAM TO CONVERT DISCRETE WORD TO BITS

COMMON/INTCOM/ICNT1,IDUM1,IDUMY,IBIT(60)

INTEGER OLDNUM

MAXBIT=15

DO 1 I=1,MAXBIT

1 IBIT(I)=0

OLDNUM=IDUM1

DO 2 I=1,MAXBIT

NEWNUM=OLDNUM/2

IBIT(I)=OLDNUM-2\*NEWNUM

OLDNUM=NEWNUM

2 CONTINUE

IHALF=MAXBIT/2

DO 3 I=1,IHALF

ITEMP=IBIT(I)

IBIT(I)=IBIT(MAXBIT+1-I)

3 IBIT(MAXBIT+1-I)=ITEMP

RETURN

END

SUBROUTINE SUB1

C  
C  
C

REAL TIME INTERRUPT SUBROUTINE

COMMON/INTCOM/ICNT1,IDUM1,ITEMP

COMMON/\*IDIS2/2,IIDIS

ICNT1=ICNT1+1

IDUM1=IIDIS

IF(ITEMP.EQ.IDUM1)GO TO 10

ITEMP=IIDIS

CALL SIMHOLD

10 CONTINUE

CALL SIMIDLE

END

RTREE TRDIS(0),SUB1(1)

GLOBAL INTCOM

END



```

PROGRAM TRDISO(OUTPUT,HFILE,TAPES=OUTPUT)

C
C PROGRAM TO INDIVIDUALLY TEST DADIOS DISCRETES FROM CDC/6600 TO AD/4
C THIS IS ACCOMPLISHED BY LETTING THE CDC/6600 SEND A BIT AND PAUSE.
C THE BIT CAN THEN BE VERIFIED AT THE AD/4 CONSOLE BY APPROPRIATE
C PATCHING TO AN INDICATOR LIGHT ON THE DIGITAL LOGIC BOARD. THE NEXT,
C AND EACH SUCCEEDING, BIT IS RAISED BY A GO COMMAND GIVEN THROUGH DDS.
C
C PROGRAM VARIABLES
C IERR          ERROR CODE FOR RESERVATION
C               (=NOERROR, GT.)=RESERVATION ERROR
C ISTAT        REAL TIME MODE
C               (=IN REAL TIME, ISTAT.GT.0 NOT IN REAL TIME
C IDUM1        DISCRETE WORD TRANSMITTED FROM CDC/6600 TO AD/4
C ICNT1        TIME SINCE LAST BIT WAS CHANGED (SECONDS)
C
C DADIOS PATCHING REQUIREMENTS (ONE OF THE FOLLOWING)
C
C TRUNKING          FORTRAN          AD/4 LOGIC
C V-51 TO W-60     FOR /ODIS2/1, IODIS  TR10-TR17 AND TR30-TR37
C V-53 TO W-60     FOR /ODIS2/1, IODIS  TR50-TR57 AND TR70-TR77
C V-51 TO W-51     FOR /ODIS2/2, IODIS  TR10-TR17 AND TR30-TR37
C V-53 TO W-61     FOR /ODIS2/2, IODIS  TR50-TR57 AND TR70-TR77
C
COMMON/INTCOM/ICNT1,IDUM1,IBIT(30)
INTERRUPT(I=1,R=20,T=100000)
COMMON/*ODIS2/2,IODIS

C
C INITIALIZATION
C
ICNT1=0
ICOUNT=0
CALL RESERVE(IERR)
WRITE(6,1000)IERR
IF(IERR.NE.0)STOP

C
C REAL TIME
C
CALL SIMRUN(ISTAT)
CALL REMARK(17H JOB IN REAL TIME)
WRITE(6,2000)ISTAT
IF(ISTAT.GT.0)STOP
WRITE(6,6000)
WRITE(6,5000)
25 CONTINUE
CALL BHOLD
IDUM1=2**ICOUNT
CALL BITS
WRITE(6,4000)IDUM1,IDUM1,(IBIT(K),K=1,16),ICNT1
ICOUNT=ICOUNT+1
IF(ICOUNT.EQ.17)ICOUNT=0
PAUSE
CALL OCTOIS(5H BITS,IDUM1)
CALL REMARK(19H RETURN TO MAIN)
ICNT1=0
CALL SIMGO
GO TO 25

```

```

1110 FORMAT(24H RESERVATION ERROR CODE=,020)
2110 FORMAY(18H REAL TIME STATUS=,020)
4000 FORMAT(5X,010,110,5X,1011,110)
5000 FORMAT(*0      OCTAL      BASE TEN      .....BITS.....      TIME*)
6000 FORMAT(*1      RECORD OF DATA SENT *)
      STOP
      END

```

# SUBROUTINE SUB1

```

C
C REAL TIME INTERRUPT SUBROUTINE
C
COMMON/INTCOM/ICNT1,IDUM1,IBIT(5)
COMMON/*ODIS2/2,IODIS
ICNT1=ICNT1+1
IODIS=IDUM1
IF(ICNT1.GT. 5)CALL SIMHOLD
CALL SIMIDLE
END

```

# SUBROUTINE BITS

```

C
C PROGRAM TO CONVERT DISCRETE WORD TO BITS
COMMON/INTCOM/ICNT1,IDUM1,IBIT(5)
INTEGER OLDNUM
MAXBIT=16
DO 1 I=1,MAXBIT
1 IBIT(I)=0
OLDNUM=IDUM1
DO 2 I=1,MAXBIT
NEWNUM=OLDNUM/2
IBIT(I)=OLDNUM-2*NEWNUM
OLDNUM=NEWNUM
2 CONTINUE
IHALF=MAXBIT/2
DO 3 I=1,IHALF
ITEMP=IBIT(I)
IBIT(I)=IBIT(MAXBIT+1-I)
3 IBIT(MAXBIT+1-I)=ITEMP
RETURN
END

```

```

RTRIEE TRDISC(0),SUB1(1)
GLOBAL INTCOM
END

```

PROGRAM TRDISIO(OUTPJT,HFILE,TAPE6=OUTPJT)

PROGRAM TO TEST DISCRETE WORDS BETWEEN AD/4 AND CDC/6600. THIS  
TASK IS ACCOMPLISHED BY TURNING AROUND BITS SENT BY THE CDC/6600  
AND COMPARING THEM UPON RETURN. THE PROGRAM TEST ALL POSSIBLE BIT  
PATTERNS FOR A 15 BIT LINE.

THE HIGH ORDER CDC-6600 BIT CORRESPONDS TO TR0X, WHERE X=0,2,4,6

#### PROGRAM VARIABLES

IERR	ERROR CODE FOR RESERVATION
	0=NOERROR, GT.0=RESERVATION ERROR
ISTAT	REAL TIME MODE
	0=IV REAL TIME, ISTAT.GT.0 NOT IN REAL TIME
IIDIS	CDC-6600 SENSE LINE DISCRETE(15 BIT) IIDIS=IBACK
IODIS	CDC-6600 CONTROL LINE DISCRETE(15 BIT) IODIS=IOUT
MAX	DEC. EQUIVALENT OF 16 BITS ALL EQUAL ONE
LOOP	NUMBER OF INTERRUPTS BEFORE EQUALITY OF BITS
LINE	NUMBER OF LINES OF PRINTOUT IN EXECUTION

#### DADIOS PATCHING REQUIREMENTS (ONE IIDIS AND ONE IODIS)

TRUNKING	FORTRAN	AD/4 LOGIC
V-50 TO W-50	FOR /IDIS2/1,IIDIS	TR00-TR07 AND TR20-TR27
V-52 TO W-50	FOR /IDIS2/1,IIDIS	TR40-TR47 AND TR60-TR67
V-50 TO W-51	FOR /IDIS2/2,IID S	TR00-TR07 AND TR20-TR27
V-52 TO W-51	FOR /IDIS2/2,IIDIS	TR40-TR47 AND TR60-TR67
V-51 TO W-50	FOR /ODIS2/1,IODIS	TR10-TR17 AND TR30-TR37
V-53 TO W-50	FOR /ODIS2/1,IODIS	TR50-TR57 AND TR70-TR77
V-51 TO W-51	FOR /ODIS2/2,IODIS	TR10-TR17 AND TR30-TR37
V-53 TO W-51	FOR /ODIS2/2,IODIS	TR50-TR57 AND TR70-TR77

COMMON/INTCOM/IOUT,LOOP,MAX,IBACK  
INTERRUPT(I=1,R=10,T=500)  
COMMON/\*IDIS2/2,IIDIS  
COMMON/\*ODIS2/2,IODIS  
CALL RESERVE(IERR)  
WRITE(6,1000)IERR  
IF(IERR.NE.0)STOP

#### INITIALIZATION

MAX=2\*\*15-1  
IOUT=0  
LOOP=1  
LINES=0

#### REAL TIME

CALL SIMRUN(ISTAT)  
WRITE(6,2000)ISTAT  
IF(ISTAT.GT.0)STOP  
CALL REMARK(17H JOB IN REAL TIME)  
WRITE(6,3000)  
WRITE(6,3000)



```

25 CONTINUE
   CALL EHOLD
   WRITE(6,4000) IOUT, IOJT, IBACK, IBACK, LOOP
   CALL SIMGO
   GO TO 25
   LINES = LINES + 1
   IF(LINES.GT.200) STOP
   WRITE(6,3000)
   CALL RLMARK(15H RETURN TO MAIN)
1000 FORMAT(24H RESERVATION ERROR CODE=,020)
2000 FORMAT(18H REAL TIME STATUS=,020)
3000 FORMAT(1H0,*PROGRAM TERMINATED NORMALLY*)
4000 FORMAT(10X,010,I15,5X,010,I15,I15)
5000 FORMAT(5X,* IOUT(OCTAL)   IOUT(DECIMAL)   IBACK(OCTAL)   IBACK(DECIM
1MAL)  LOOP(DECIMAL)*//)
6000 FORMAT(///,35X,*ERRORS DETECTED*//)
   STOP
   END

```

# SUBROUTINE SUB1

```

C
C   REAL TIME INTERRUPT SUBROUTINE
C
COMMON/INTCOM/IOUT,LOOP,MAX,IBACK
COMMON/*IDIS2/2,IIDIS
COMMON/*ODIS2/2,IODIS
IODIS=IOUT
IBACK=IIDIS
IF(IOUT.NE.IBACK) GO TO 10
IF(IOUT.EQ.MAX) IOJT=J
IOUT=IOUT+1
LOOP=L
10 LOOP=LOOP+1
IF(LOOP.EQ.10) CALL SIMHOLD
CALL SIMBLE
END

```

```

RTREE TRD(SIO(0),SUB1(1))
GLOBAL INTCOM
END

```



```

PROGRAM TRALGI(OUTPUT,HFILE,TAPE6=OUTPUT)

C
C PROGRAM TO TEST DADIOS ADDS FROM AD/4 TO CDC/6600. THIS IS
C ACCOMPLISHED BY PATCHING AN ANALOG SIGNAL TO THE DESIRED AD/4
C TRUNK LINE. EACH TIME THE AD/4 SIGNAL CHANGES THE CDC/6600 RECORDS
C THE NEW ANALOG SIGNAL.
C
C PROGRAM VARIABLES
C IERR ERROR CODE FOR RESERVATION
C D=NOERROR, GT.0=RESERVATION ERROR
C ISTAT REAL TIME MODE
C 0=IN REAL TIME, ISTAT.GT.0 NOT IN REAL TIME
C PERCENT PERCENT CHANGE REQUIRED IN ADD VALUE BEFORE NEW
C ADD VALUE IS RECORDED BY CDC/6600
C LINE NUMBER OF LINES OF PRINTOUT IN EXECUTION
C
C NOTE ADDS ARE IN GROUPS OF 16, 1-16, 17-32, 33-48, 49-64.
C FLOATING POINT ANALOG SIGNALS ARE SCALED GE -1.0 AND LE +1.0.
C INTEGER ANALOG SIGNALS ARE SCALED GE -32767 AND LE +32767(14 BIT).
C
C DADIOS PATCHING REQUIREMENTS (ONE OF THE FOLLOWING)
C
C TRUNKING FORTRAN AD/4 LOGIC
C W-03 TO V-06 FOR /*ADC1/49,ADD TR10-TR17 AND TR30-TR37
C
C COMMON/INTCOM/BACK,LOOP,PERCENT,TEMP
C INTERRUPT(I=1,R=10,T=5000)
C COMMON/*ADC1/49,ADD
C
C INITIALIZATION
C
C PERCENT=.05
C LINE=0
C TEMP=0.0
C CALL RESERVE(IERR)
C WRITE(6,1000)IERR
C IF(IERR.NE.0)STOP
C
C REAL TIME
C
C CALL SIMRUN(ISTAT)
C WRITE(6,2000)ISTAT
C IF(ISTAT.GT.0)STOP
C CALL REMARK(17H JOB IN REAL TIME)
C WRITE(6,3000)
C 25 CONTINUE
C CALL EHOLD
C LINE=LINE+1
C IF(LINE.GT.200)STOP
C LOOP=0
C WRITE(6,3000)BACK,LOOP
C CALL SIMO
C GO TO 25
C
1000 FORMAT(24H1RESERVATION ERROR CODE=,020)
2000 FORMAT(18H REAL TIME STATUS=,020)

```

```

3000 FORMAT(5X,F10.4,I10)
6000 FORMAT('0 RECORD OF DATA RECEIVED BY CDC/6600*//')
STOP
END

```

```

SUBROUTINE SUB1

```

C  
C  
C

```

REAL TIME INTERRUPT SUBROUTINE

```

```

COMMON/INTCOM/BACK,LOOP,PERCENT,TEMP

```

```

COMMON/*ADC1/49,ADC

```

```

LOOP=LOOP+1

```

```

BACK=ADC

```

```

PCHANGE=ABS(ABS(TEMP)-ABS(BACK))/ABS(TEMP)

```

```

IF(PCHANGE.GT.PERCENT)GO TO 10

```

```

TEMP=ADC

```

```

CALL SINHOLD

```

```

10 CONTINUE

```

```

CALL SIMIDLE

```

```

END

```

```

RTREE TRALGI(0),SUB1(1)

```

```

GLOBAL INTCOM

```

```

END

```

```

PROGRAM TRALGO(OUTPUT,HFILE,TAPES=JUIPUT)
C
C PROGRAM TO INDIVIDUALLY TEST DADIOS DACS FROM CDC/6600 TO AD/4.
C THIS IS ACCOMPLISHED BY LETTING THE CDC/6600 GENERATE A FUNCTION
C F=F(TIME). THE FUNCTION CAN BE VERIFIED AT THE AD/4 CONSOLE BY
C APPROPRIATE PATCHING TO A RECORDER.
C
C PROGRAM VARIABLES
C IERR          ERROR CODE FOR RESERVATION
C               (=NOERROR, GT.0=RESERVATION ERROR)
C ISTAT         REAL TIME MODE
C               C=IN REAL TIME, ISTAT.GT.0 NOT IN REAL TIME
C TIME          INDEPENDENT VARIABLE WHICH IS PROPORTIONAL TO
C               REAL TIME
C DAC           THE DAC VARIABLE, NOTE OUT=DAC
C
C NOTE DACS ARE IN GROUPS OF 16, 1-16, 17-32, 33-48, 49-64.
C FLOATING POINT ANALOG SIGNALS ARE SCALED GE -1.0 AND LE +1.0.
C INTEGER ANALOG SIGNALS ARE SCALED GE -32767 AND LE +32767 (14 BIT).
C
C DADIOS PATCHING REQUIREMENTS (ONE OF THE FOLLOWING)
C
C TRUNKING          FORTRAN          AD/4 LOGIC
C W-13 TO V-37     FOR /*DAC1/49,DAC   TR50-TR57 AND TR70-TR77
C
COMMON/INTCOM/OUT,TIME,LOOP
INTERRUPT(I=1,R=10,T=5000)
COMMON/*DAC1/49,DAC
C
C INITIALIZATION
C
TIME=0.0
CALL RESERVE(IERR)
WRITE(6,1000)IERR
IF(IERR.NE.0)STOP
C
C REAL TIME
C
CALL SIMRUN(ISTAT)
WRITE(6,2000)ISTAT
IF(ISTAT.GT.0)STOP
CALL REMARK(17H JOB IN REAL TIME)
25 CONTINUE
CALL BHOLD
1000 FORMAT(24H1RESERVATION ERROR CODE=,020)
2000 FORMAT(18H REAL TIME STATUS=,020)
3000 FORMAT(5X,F10.4,I10)
STOP
END

```



SUBROUTINE SUB1

C

C

C

REAL TIME INTERRUPT SUBROUTINE

COMMON/INTCOM/OUT,TIME,LOOP

COMMON/\*DAC1/49,DAC

TIME=TIME+.11

IF (TIME.GT.6.28) TIME=0.0

OUT=SIN(TIME)

DAC=OUT

CALL SIMIDLE

END

RTREE TRALGO(0),SUB1(1)

GLOBAL INTCOM

END



```
PROGRAM TRALGIO(OUTPUT,HFILE,TAPE6=OUTPUT)
```

```
PROGRAM TO TEST ANALOG SIGNALS BETWEEN AD/4 AND CDC/6600. THIS TASK  
IS ACCOMPLISHED BY TURNING THE ANALOG SIGNAL AROUND AT THE AD/4 AND  
COMPARING DIFFERENCE UPON RETURN TO THE CDC/6600. THE PROGRAM TEST  
FOR ERRORS GREATER THAN FIVE PERCENT.
```

```
NOTE ADCS AND DACS ARE IN GROUPS OF 16, 1-16, 17-32, 33-48, 49-64.  
FLOATING POINT ANALOG SIGNALS ARE SCALED GE -1.0 AND LE +1.0.  
INTEGER ANALOG SIGNALS ARE SCALED GE -32767 AND LE +32767(14 BIT).
```

# ``` PROGRAM VARIABLES ```

```
IERR          ERROR CODE FOR RESERVATION  
               C=NOERROR, GT.0=RESERVATION ERROR  
ISTAT          REAL TIME MODE  
               C=IN REAL TIME, ISTAT.GT.0 NOT IN REAL TIME  
OUT            THE DAC VARIABLE  
BACK           THE ADC VARIABLE  
PERCENT        MAXIMUM ALLOWABLE PERCENT ERROR  
PERROR         ACTUAL COMPUTED PERCENT ERROR  
LINE           NUMBER OF LINES OF PRINTOUT IN EXECUTION
```

```
DADIOS PATCHING REQUIREMENTS (AD/4 FIELD 3, 4TH GROUP ADC AND DAC)
```

TRUNKING	FORTRAN	AD/4 LOGIC
W-03 TO V-06	FOR /*ADC1/49,ADC	TR10-TR17 AND TR30-TR37
W-13 TO V-17	FOR /*DAC1/49,DAC	TR50-TR57 AND TR70-TR77

```
COMMON/INTCON/OUT,LOOP,BACK,PERCENT,PERROR  
INTERRUPT(I=1,R=14,T=500)  
COMMON/*ADC1/49,ADC  
COMMON/*DAC1/49,DAC
```

## ``` INITIALIZATION ```

```
PERCENT=.05  
OUT=0.0  
BACK=0.0  
LOOP=0  
LINE=0  
CALL RESERVE(IERR)  
WRITE(6,1000)IERR  
IF(IERR.NE.0)STOP
```

## ``` REAL TIME ```

```
CALL SIMRUN(ISTAT)  
WRITE(6,2000)ISTAT  
IF(ISTAT.GT.0)STOP  
CALL REMARK(17H JOB IN REAL TIME)  
25 CONTINUE  
CALL BOLD  
LINE=LINE+1  
IF(LINE.GT.200)STOP  
WRITE(6,4000)OUT,BACK,PERROR,LOOP  
CALL SIMGO
```

```

GO TO 25
WRITE(6,3000)
1000 FORMAT(24H RESERVATION ERROR CODE=,020)
2000 FORMAT(18H REAL TIME STATUS=,020)
3000 FORMAT(1H0,*PROGRAM TERMINATED NORMALLY*)
4000 FORMAT(5X,3F10.4,110)
STOP
END

```

# SUBROUTINE SUB1

C  
C  
C

REAL TIME INTERRUPT SUBROUTINE

```

COMMON/INTCOM/OUT,LOOP,BACK,PERCENT,PERROR
COMMON/*ADC1/1,ADC
COMMON/*DAC1/1,DAC
DAC=OUT
BACK=ADC
PERROR=ABS((OUT-BACK)/OUT)
IF(PERROR.GT.PERCENT)GO TO 10
IF(OUT.GT.0.99)OUT=0.0
OUT=OUT+.015
LOOP=0
10 LOOP=LOOP+1
IF(LOOP.EQ.10)CALL SIMHOLD
CALL SIMIDLE
END

```

```

$FREE FRALGIC(0),SUB1(1)
GLOBAL INTCOM
END

```